



## Tube Pro™ Inc. OVERLAP SEAM Waterpark Tube Inflation/Deflation Instructions

### INFLATION:

Remove the PVC vinyl tube from the packaging and make sure to save the repair patches & glue included in the plastic bag. When preparing to inflate the tube, lay the tube down with the graphics facing upward and spread out as flat as possible.

To inflate the main chamber of the tube, make sure the 3/4" recessed safety valve is securely tightened by turning the square textured base of the valve cap to the right. Next, loosen the round top of the valve cap by turning it to the left, while ensuring the square base stays securely tightened. Inflate the main chamber of the tube using a small air compressor, air mattress pump or blower until the tube takes shape and is fully inflated. Our custom PVC vinyl tube takes shape quickly during inflation. Do not over inflate the main air chamber of the vinyl tube. To seal the safety valve cap securely tighten the cap by inserting a slot screwdriver or coin into the slot and turn the round top to the right. Refer to the Tube Pro™ photo at the bottom of page for a properly inflated tube.

### DEFLATION/STORAGE:

To deflate the main air chamber of the tube, remove the entire safety valve cap from the recessed valve port. To loosen valve cap turn the square textured base to the left. Fold and curl tube as necessary to remove excess air. Once the vinyl PVC tube is deflated, reinstall the 3/4" valve core and tighten cap securely at the base for storage. Vinyl tubes should be stored without sharp creases in the PVC. Do not tightly vacuum the tube.

*Note: Tube may naturally deflate due to seasonal air pressure changes. Additional air may be required before use.*

### RE-INFLATION:

**\*\*When re-inflating vinyl tubes, ensure the main chamber 3/4" safety valve is screwed tightly.\*\***

### PATCH REPAIRS:


Each waterpark tube includes two PVC patch pieces and 1 small glue tube for repairs. For best results, ensure tube repair area is clean and dry. Cut a smaller circular patch piece as needed for the repair area. Apply a thin layer of glue to the cut circular patch and around the tube area where air is escaping. After allowing a few minutes for the glue to 'tack', place the patch on the leaky area and apply pressure to smooth and adhere the patch to the tube. Secure the patch with a weight or small clamp. The glue provided is urethane based and creates a strong chemical bond as the solvent evaporates.

For best results the glue will need to dry for a couple hours, allowing time for curing and maximum bond.



Read warning label on product prior to using.

### International Safety Alert Warning Descriptions



	This is the safety alert symbol. It is used to alert you to potential personal injury hazards.
	<b>WARNING</b> indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
<b>WARNING</b>	
This product is not a lifesaving device. Do not leave children unattended while in use. Use only under competent supervision. Always sit upright when riding/floating. Do not jump or dive on product. Do not tow behind watercraft and other vehicles. Always wear a life jacket in deep water. Inspect item condition before each use. Do not use damaged product. Reluctance to follow guidelines may result in injury or product failure. Refer to instructions for proper inflation of product, description of safety warnings and recommended rider capacity.	
Tube Pro Inc., Made in China	

Have fun and be careful.

Tube Pro Inc.